

OPERATING MANUAL




Baby stroller


**IMPORTANT! READ CAREFULLY AND KEEP
FOR FUTURE REFERENCE.**

FUNCTION


Baby stroller parts instructions




PARTS




► Frame*1



► seat*1



► Front armrest*1



► Front wheels*2




► Rear wheels*2

INSTRUCTIONS


Instructions

Unfold the stroller

Release the locking latch, pull the handle up to deploy the stroller. It will open automatically and lock into position after hearing a “click”.



Installation and removal of front wheels



Installation of front wheels: Align the axle of the front wheel set with the hole of the front foot socket and insert it until a clear “click” sound is heard. Pull the wheel in the opposite direction to confirm whether the wheel is installed in place. Install the other front wheel in the same way.

Quick removal of front wheels: Press and hold the front wheel quick release button on the outside of the front wheel seat and pull the front wheel out of the front foot tube at the same time.

INSTRUCTIONS

Instructions


Installation and removal of rear wheels

Installation of rear wheels: Insert the rear wheel bearing into the rear wheel slot of the vehicle platform. After hearing the click sound, the installation is completed.

Removal of rear wheels: Find the rear wheel removal rod on the rear wheel slot, pull it up, and then pull out the rear wheel axle to complete the rear wheel disassembly.


Rear axle installation: Insert the rear foot tube bracket directly into the rear axle, and the installation is complete when you hear a click.

Rear axle removal: Find the quick release button of the rear axle, press it, and pull out the rear wheel set to complete the removal.



Seat installation

After the front and rear wheels of the frame are installed, then install the seat section. First, we vertical the seat, pick it up, align it with the red mark on the large joint on the frame circle, and then insert the seat into the deckard slot.




INSTRUCTIONS

Instructions

Usage for the front wheels


Front wheel orientation: Turn the front wheel orientation spanner upward to direct the front wheel and make the cart go straight.

Universal wheel of front wheel: turn the directional spanner of front wheel downward to release the directional wheel and rotate the front wheel 360°.



Usage for the rear wheels brake

Rear wheel brake: Depress the rear wheel brake pedal down, the rear wheel brakes, and the stroller cannot be pushed; On the contrary, turn the brake pedal upward and lift it up to unlock the rear wheel and the stroller can be pushed.



Warning: Before stopping the stroller or letting the baby in or out of the stroller, the brakes must be put on.

INSTRUCTIONS

Instructions


Adjustment and usage for seat belt

Combine: Insert the belt plug into the shoulder belt buckle


Buckle: Insert the plug-in parts of both left side and right side into the center buckle separately, until hearing a clear “click” sound.

Open: Press the center button of the five-point seat belt buckle, then open the two separate sets of buckles on both sides to unlock the seat belt.

Adjust: Stretch the webbing in the direction of the arrow to adjust the length.




COMBINE



BUCKLE



OPEN



ADJUST



WARNING: When baby in the stroller, seat belts should be duckle up!

Install and remove the front armrest


Installation: Insert both ends of the front armrest into the corresponding handrail joints on both sides to complete the installation of the front armrest.

Removal: Press the remove button on both sides of the armrest and pull out the front armrest.


Install



Remove




remove button




INSTRUCTIONS

Instructions

 Seat adjustment



 Adjusting the footrest





First gear: Pull the footrest out to the edge and put down.
Second gear: Lift straight up.

INSTRUCTIONS


Instructions

Seat reversal



① Press the button to pull out the seat.

② Switch direction, align and insert frame.



③ Complete the reversing operation.

When the seat is reversed, children should not ride in the sleeping basket (or seat).




INSTRUCTIONS

Instructions

Fold the stroller



① Closed roof





② Lay the seat flat




③ Fold the footrest

④ Press the fold button on the armrest (press and hold the red button at the same time hold the yellow button)



⑤ Fold down the handle



⑥ Buckle the coupler, finished folding

WARNING



IMPORTANT - READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

- ▶ Never leave the child unattended.
- ▶ Ensure that all the locking devices are engaged before use.
- ▶ To avoid injury ensure that the child is kept away when unfolding and folding this product.
- ▶ Do not let the child play with this product.
- ▶ Use a harness as soon as the child can sit unaided.
- ▶ Always use the restraint system.
- ▶ Check that the pram body or seat unit or car seat attachment devices are correctly engaged before use.
- ▶ This product is not suitable for running or skating.
Do not use on the escalator or stairs.
- ▶ This product is suitable for children from 0 to 36 months.
The maximum load bearing is not more than 15KG.
- ▶ The stroller can only seat one child.
- ▶ Any load attached to the handle and/or on the back of the backrest and/or on the sides of the vehicle will affect the stability of the vehicle.
- ▶ Do not use the front handrail as the handle of the cart to lift the platform or children, so as to avoid unnecessary injuries caused by the handrail falling off.
- ▶ Do not park the cart on the slope.
- ▶ The maximum load bearing of the basket is 2kg.
- ▶ The parking device shall be engaged when placing and removing the children.
- ▶ Only replacement parts supplied or recommended by the manufacturer/distributor shall be used.
- ▶ New born baby shall use the most reclined position.
- ▶ Keep away from fire.

CARE AND MAINTENANCE

- ▶ Clean your COBALLE stroller with a non-toxic, non-abrasive cleanser mix a solution of water and a small amount of mild, non-toxic detergent and wipe with a damp cloth onto the frame. Do not use detergent or solution.
- ▶ If it is necessary to leave the stroller idle for a period of time, do not store it in a humid or hot environment, otherwise it will easily lead to rusting and aging of parts, which may cause air circulation around the seat.
- ▶ Do not put anything on the seat to avoid affecting the service life of the product or causing danger.
- ▶ Please use a rainshield when it rains, dry the cart before folding and storing it.
- ▶ Check regularly for loose screws, damaged parts or broken stitches. Stop using if parts are damaged.

Product Warranty Description

▶ Quality guarantee clause

The warranty provides free maintenance services.

Please contact our after-sales department or purchase store for further information.

▶ Product Warranty Description

- 1.If the product breaks down within one year from the date of purchase, it can be repaired free of charge. In the case of non-warranty problems or beyond the warranty period, the company can provide repair services for you, but the corresponding repair cost will be charged.
- 2.The warranty shall provide the quality guarantee, please keep it properly.
- 3.During the warranty period, the following problems do not belong to the warranty scope:
 - A.The color change caused by natural aging of plastics.
 - B.Failure or damage caused by incorrect use, modification or improper maintenance.
 - C.Damage caused by improper maintenance
(e.g. temperature water inlet extrusion).