

Product parts



Attention, police

Users and guardians are advised to read this manual carefully before use and keep it for future reference. Failure to follow this manual may affect the safety of children.

Security Alert

- When the child rides, the caregiver does not leave.
- Any load placed on the handle will affect the stability of the vehicle.
- Make sure all locking devices are locked before using the trolley.
- Children must fasten their seat belts when riding.
- Do not add more than 20 mm thickness of cotton pad in the cart.
- When the angle between the backrest and the cushion is less than 150°, the CART is not suitable for children under 6 months of age.
- It is forbidden to use parts not supplied by the original manufacturer.

Points to note and how to use

- 1.Back-to-back adjustment must be performed by the child's caregiver.
- 2.Care should be taken not to let the child climb out of the fence or stand on the seat.
- 3.Do not lift when carrying a child.
- 4.Do not use near the stove, pool or other dangerous places. Tarpaulin is flammable. Do not go near the fire.
- 5.The vehicle is not allowed to be used in dangerous areas such as places where it is easy to roll over and uneven.
- 6.Two or more people are not allowed to ride in the same car.
- 7.It is forbidden to remove the head baffle when the stroller is used as a baby bed.
- 8.The wheels must be stopped when not moving.
- 9.Please put away the packing bag in time to avoid suffocation caused by children's play.
- 10.The maximum loading capacity of the bin Blue is 2KG.
- 11.The maximum load of the trolley pallet is 2KG.

Certificate

Models: _____

Inspector: _____

Date: _____

Maintenance and repair

To ensure your baby from accidental injury, please check and maintain the car regularly. When the cloth cover is cleaned, please use the brush to clean the stain directly. The other parts are washed with soap. Regularly check whether the parts are damaged or whether the stitches are broken, please replace the damaged parts. Should avoid the baby carriage is often exposed to direct sunlight and wind and rain, affect the service life.

Quality Guarantee

Children's carriage regular inspection supervision, from raw materials to product factory production process are strictly controlled and product quality inspection.

The stroller is mainly made of steel, plastic and textile. It is made of safety materials. For each customer to provide quality after-sales service, is our long-term follow the principle. If you cause damage to the whole vehicle or spare parts in use, please contact our after-sales service or our special service point or sales point for maintenance.




Instruction manual

Child stroller

Installation steps


一、Install handrails (As shown in the following figure)

First, take the cart out of the box, put the cart on the ground on four legs, two hands holding the push handle up, heard the "Click" sound, that is, in a locked state (Figure 1), then the armrest at both sides of the body parallel holes inserted into the body (as shown in Figure 2), heard the "Click" sound plug into place, while pressing the button under the armrest can be pulled out of the armrest (as shown in Figure 3).



二、Install the crotch strap (As shown in the following figure)

Turn the crotch band around the armrest (figure 4) and press the button down hard (figure 5).




三、Install the front wheel (As shown in the following figure)

The front wheel plate ends down, press the plate into the front leg shaft (Figure 6) insert into the main wheel, (Figure 7).




四、Install rear wheel and brake function (As shown in the following figure)

Brake backward to the back legs of the tube sleeve (Figure 8) to insert the tube sleeve, can not be inserted in the opposite direction, hear the "Click" sound, the tube sleeve hole exposed the clamp spring that is stuck in place, (figure 9) brake pressure can brake, lift up and release the brake (figure 10).



五、Adjust backrest and sunshade (As shown in the following figure)

Use Your Hand to press down on the backrest adjustment button, adjust the backrest angle according to the situation (Figure 11), open and fold the awning can be opened (figure 12).




六、Seat Belt and pedal adjustment (As shown in the following figure)

Press the red button on the seat belt button to release the seat belt (figure 13). Press the shrapnel under the foot to adjust the angle (figure 14).



七、Retracting device (As shown in the following figure)

Please fold the awning before folding, and then fold it as shown in figure 15, 16, 17.



Mosquito net fixation Cup holder fixing place



After folding, the red hook is fixed to prevent the frame from falling apart.

